

Bond Guard ZRC-333

NON-PHOSPHATED SURFACE TREAT & CLEAN

BOND GUARD ZRC-333 is a non-phosphated cleaner & conversion treatment for bonding and providing corrosion resistance for paint coatings on steel and non-ferrous metals. Provides low-temperature operation and a greener pretreatment process. It can be used as a conversion coating and the final dry-in-place rinse sealer.

BOND GUARD ZRC-333 promotes coatings on difficult surfaces of both ferrous and non-ferrous metals. ZRC is highly effective on weldment areas and high-alloy surfaces, which can typically be a problem with conventional pretreatments. Provides superior quality of top coatings and finishes.

BOND GUARD ZRC-333 zirconium technology enhances finished product quality by providing a wider window of process capability and repeatable performance under paints and coatings. Highly effective on aluminum surfaces.

Features & Benefits

- Phosphate Free
- Low Temperature Energy Savings
- High Performance
- Very low use cost.
- Reduced Maintenance
- Lower Sludging
- Concentrated liquid that easily mixes in water.
- Provides equivalent or improved performance over conventional phosphate treatments before paints and coatings

Physical Data

Specific gravity	1.04
Product Type	Liquid
pH (5%)	4.0 – 4.6
Lbs./Gal	8.84
Foam, 0=Low 9=High	0
Shelf-Life Years	10 Years
Freeze Information	Not Damaged by Freezing

Typical Processing

- 1) Clean
- 2) Rinse
- 3) BOND GUARD ZRC 333: 3 – 4% by volume, 70° – 110° F., 45 – 90 sec., pH 4.0 – 5.0
 - a. (steel pH 4.4 – 5.0, nonferrous pH 3.8 – 4.4)
- 4) Rinse
- 5) DI or RO rinse, or final seal rinse for maximum quality.
 - a. **optional no rinse process for nonferrous if required. Dry in place.
- 6) Hot air dry prior to powder coat.

Operating Conditions

Concentration Range	2 – 4% by volume
Temperature Range	70 - 110° F.
Time Range	30 – 90 seconds
Agitation	Per system

Maintain pH of 4.0 – 5.0

To lower the pH: Use pH Adjuster ZRC

To raise the pH or lower free acid: Use pH Conditioner #4

(pH Control: steel pH 4.4 – 5.0, nonferrous pH 3.8 – 4.4)

Titration Method

- 1) Take A 10ml Sample (pH Must Be in Operating Range)
- 2) Add 3-5 Drops of Phenolphthalein Indicator
- 3) Titrate with 0.1N NaOH until a permanent pink appears.
- 4) The Number of Mls Required = % By Volume

Test Kit Method

Total Acid/Concentration: (Target Equals 6-12 Drops)

- 1) Take A 10ml Sample (pH Must Be in Operating Range)
- 2) Add 3-5 Drops of Phenolphthalein Indicator
- 3) Add Drop by Drop (count the drops) of 0.1N NaOH until a permanent pink appears
- 4) The Number of Drops Required Multiplied by a Factor of 0.35 = % by Volume

Free Acid/Consumed Acid: (Target Equals 0-1 Drops)

- 1) Take A 10ml Sample (pH Must Be in Operating Range)
- 2) Add 3-5 Drops of Bromo Blue Indicator
- 3) If Blue (consumed acid): Titrate with 0.1N acid
 If Yellow (free acid): Titrate with 0.1N NaOH (do not operate with free acid, use adjustments)



Product Bulletin

Product Name: Bond Guard ZRC-333
Product Code: 2204903
Revision Date: March 26, 2026

Waste Disposal

NEUTRALIZE, REMOVE METALS IF PRESENT

Holding Tank Materials of Construction

ACID RESISTANT, STAINLESS OR POLY

Caution

BOND GUARD ZRC 333 is a mildly acidic solution. Wear protective clothing, gloves, and goggles when handling this product. Flush exposed areas immediately with clean, cold water. For the eyes, flush repeatedly with water and call a physician.

WARRANTY: HUBBARD-HALL INC. IS NOT RESPONSIBLE FOR THE MISUSE, MISAPPLICATION, OR MISHANDLING OF THIS PRODUCT. SEE THE TERMS AND CONDITIONS OF SALE ON OUR WEBSITE FOR ADDITIONAL TERMS AND CONDITIONS CONCERNING OUR PRODUCTS, INCLUDING BUT NOT LIMITED TO, LIMITATIONS AND DISCLAIMERS OF WARRANTIES AND LIABILITIES.

Our People. Your Problem Solvers.

For more information on this process,
please call us at 203.756.5521 or email: techservice@hubbardhall.com

Hubbard-Hall holds certifications for **ISO 9001:2015**, Responsible Distribution, as accredited by the **ACD** (Alliance for Chemical Distributors) and as a **Women-Owned Small Business**, as well as maintaining an association with **Omni-Chem**¹³⁶.