

Mi-Phos™ C Sealer

Mi-Phos C Sealer is a concentrated acidic solution which is used to seal the Mi-Phos phosphate coatings as well as provide added corrosion resistance to the finished part.

Features & Benefits

Meets MIL-DTL-16232	Conforms to phosphating specification
---------------------	---------------------------------------

Operating Conditions

EQUIPMENT

The processing tank, pump and piping for the Mi-Phos C Sealer solution can be constructed of mild steel. Nozzles should be constructed of stainless steel for longer life; however, mild steel can be used.

Processing sequence

Mi-Phos C Sealer solution is applied to the phosphate parts then dried on by forced heat or air dry.

Parts that have been phosphated and rinsed are introduced to Mi-Phos C Sealer solution for 30 to 60 seconds at room temperature to 160°F.

A working solution of Mi-Phos C Sealer is made up by adding 3 to 6 fluid ounces of Mi-Phos C Sealer concentrate to 100 gallons of water.

The sealer solution can then be used until the ratio gets to 7 parts Total Acid to 1-part Free Acid. At this point, the sealer solution should be discarded and a new one made up.

Titration Method

Control procedure

Mi-phos C sealer analysis

EQUIPMENT REQUIRED

25 mL Burette
10 mL Graduated Cylinder
15 %w/w Potassium Iodide Solution
25 mL Graduated Cylinder
0.1 N Sodium Thiosulfate Solution
250 mL Graduated Cylinder
500 mL Erlenmeyer Flask

CHEMICALS REQUIRED

6 N Hydrochloric Acid Solution

20 %w/w Thyodene Soluble Starch Solution

1. Using a 250 mL graduated cylinder, pour a 250 mL cooled sample of the Mi-Phos C Sealer bath into the 500 mL Erlenmeyer flask.
2. Add 10 mL of 6 N Hydrochloric Acid solution and swirl to mix.
3. Add 20 mL 15% Potassium Iodide solution and swirl to mix.
4. Let stand for 5 minutes.
5. Titrate using 0.1 N Sodium Thiosulfate solution to just a straw yellow color. Do not over titrate.
6. Add 1-2 mL of the Thyodene starch indicator. Solution will turn dark blue.
7. Continue titrating dropwise until blue just disappears. Solution will be clear or slightly green in color.
8. Record the mL of 0.1 N sodium thiosulfate used.

Calculate the oz/100 gal of Mi-Phos C Sealer as follows:

$$\text{Mi-Phos C Sealer (oz / 100 Gal)} = \text{mL 0.1 N Sodium Thiosulfate Solution} \times 0.66$$

Product Bulletin

Product Name: Mi-Phos™ C Sealer

Product Code: 2201011

Revision Date: February 6, 2025

Total and Free Acid Analysis

EQUIPMENT REQUIRED

25 mL Burette
100 mL Graduated Cylinder
250 mL Erlenmeyer Flask
0.1 N Sodium Hydroxide Solution

CHEMICALS REQUIRED

Bromophenol Blue Indicator
Phenolphthalein Indicator

1. Pour a 100 mL cooled sample of the Mi-Phos C Sealer bath into a 250 mL Erlenmeyer flask.
2. Add 10 drops of bromophenol blue indicator and 10 drops of Phenolphthalein indicator and swirl to mix.
3. Titrate slowly using 0.1 N Sodium Hydroxide solution to a deep green endpoint. Record the volume of titrant. This represents the Free Acid.
4. Continue titrating to a purple endpoint. Record volume of 0.1 N Sodium Hydroxide solution used. This volume represents the Total Acid.
5. Calculate the Total Acid: Free Acid Ratio as follows:

$$\text{Total Acid: Free Acid} = (\text{mL in Step 4}) / (\text{mL in Step 5})$$

Ratio of total acid to free acid must be LESS THAN 7.1.

If ratio is 7.1 or greater, bath should be dumped and made up fresh.

Waste Disposal

Mi-Phos C Sealer contains chromic acid. Our Aquapure team can assist you with the appropriate wastewater disposal method.



Product Bulletin

Product Name: Mi-Phos™ C Sealer

Product Code: 2201011

Revision Date: February 6, 2025

Caution

Solution should be adequately exhausted. Do not get in eyes, on skin or clothing. Do not breathe the mist from the solution. In case of contact, immediately flush skin or eyes with plenty of water for at least 15 minutes. For eyes, get medical attention. Read and understand OSHA safety data sheet for this product.

WARNING...POISON - DANGER - STRONG OXIDANT - CONTAINS CHROMIC ACID



WARRANTY: HUBBARD-HALL INC. IS NOT RESPONSIBLE FOR THE MISUSE, MISAPPLICATION, OR MISHANDLING OF THIS PRODUCT. SEE THE TERMS AND CONDITIONS OF SALE ON OUR WEBSITE FOR ADDITIONAL TERMS AND CONDITIONS CONCERNING OUR PRODUCTS, INCLUDING BUT NOT LIMITED TO, LIMITATIONS AND DISCLAIMERS OF WARRANTIES AND LIABILITIES.

Our People. Your Problem Solvers.

For more information on this process,
please call us at 203.756.5521 or email: techservice@hubbardhall.com

Hubbard-Hall holds certifications for **ISO 9001:2015**, Responsible Distribution, as accredited by the **ACD** (Alliance for Chemical Distributors) and as a **Women-Owned Small Business**, as well as maintaining an association with **Omni-Chem**¹³⁶